

XLOCK 181

 Bluetooth™



X LOCK

INSTALLATION Guide

PACKAGING CONTENTS


Lock
XL181



1 pcs 4 x 40 mm
2 pcs 4 x 25 mm

Attention:
Closing part XL-S2
- please order separately. All information on
the various closing parts can be found on
the next page.

Closing part
XL-S2



4 x lens head 3 x 12 mm.

Attention:
Please order batteries
separately.


Battery 2CR5,
6V lithium battery




**Always use lithium
batteries!**

DIMENSIONS

Lock
XL181



Closing part
XL-S2



Optional ! Please order separately.




XLOCK Closing part
with ejector
XL-S2
incl. mounting material



XLOCK Closing part
XL-S1
incl. fixing material full metal
roller predetermined breaking
point (definable)



XLOCK Closing part
XL-S5
suitable for F10 adapter adjustable
closing part for glass doors 4-6mm
incl. fixing material



XLOCK Closing part
with ejector
XL-S0
incl. mounting material



XLOCK Closing part
XL-ZS4-B
incl. mounting material full
metal roller 3 fixing points




XLOCK Closing part
XL-S2B
incl. fixing material full metal
roller predetermined
breaking point (definable)




XLOCK Closing part
XL-ZS4-B
incl. mounting material full
metal roller 3 fixing points


Optional ! Please order separately.



Adapter for espagnolette lock
XL-F8
6mm roller with recess



Adapter for espagnolette lock
XL-F9
8mm roller with recess



Latch adapter
XL-F6
flexible bolt base made of solid
metal screwed sheet metal part



Adapter for glass vitrine doors
XL-F10
Deflection unit 90°

PREPARATION FROM THE LOCK



1 pieces 2CR5, 6V lithium batterie.

For error-free operation, please always use lithium batteries!

Open the battery compartment cover and insert the batteries with the correct polarity (+/-).

Close the battery compartment cover and fix it with the screw.

Your lock is now ready for use.

INSTALL THE APP AND CREATE AN ACCOUNT



XL Lock Manager App and on the Install smartphone (IOS + Android).


Simply scan the QR code with your camera:



After installation, create your XLOCK account and confirm in the e-mail - > done.


Attention for Android devices:

For Android devices, the following permissions must be granted without restrictions for the commissioning of Bluetooth devices: **Location and Bluetooth**
In retrospect, this is no longer possible with some devices. Then you have to uninstall and reinstall the app and then restart the device.




For the commissioning of an XLOCK lock, the **location** and **Bluetooth** must be activated in the Android system!


CREATE ACCOUNT




1. Tap the button above.



2. Enter your email address and choose a password. To confirm, password again type. Tap Register.




3. Verify your account by clicking on the confirmation link in the XLOCK e-mail in your e-mail inbox button. It may be that the confirmation email has landed in your spam folder.




4. Congratulate! You have successfully installed the XL LOCK Manager app.

ADD NEW LOCK IN YOUR ACCOUNT



1. Tap the button at the bottom right corner.



2. Tap **New Lock**.

3. Have XLOCK lock ready? Press and hold the reset button with a screwdriver.



4. The lock is displayed with its ID number. Tap on the green **+** one to add your XLOCK.




5. Give the lock a name and tap **ADD**.




6. The XLOCK lock has now been successfully linked to the XLOCK APP and is visible on the start screen.


ADD TRANSPONDERS




1. Tap the lock. The lock menu opens.




2. Tap the **NFC Tags** card icon.



3) Tap that in the lower right corner to open the tag Add.



4) Select Bluetooth and tap **Next**.



5) Give the transponder a name. Tap **Next**, the lock starts the learning process.

6) The lock signals when it is ready. Then, as shown in the photo, hold the transponder to the antenna from the lock.



7) Your transponder is now stored and unlocks the lock when held to the antenna.

UNLOCK and LOCK




Hold a programmed transponder against the lock's antenna. The reading distance depends on the installation and the medium. The lock unlocks and the drawer can be opened. After 5 seconds, the lock locks automatically. The locking time can be adjusted in the app in the lock settings: 5-900 seconds



Unlocking with the smartphone and the app is very simple. A swipe to the right unlocks the lock for 5 seconds. The reading distance is up to 15 meters. Therefore, the lock can also be installed hidden, e.g. behind a drawer. The toggle mode (open-close function) can also be used with the smartphone. This function is activated and deactivated in the app in the lock menu.




MOUNTING LEFT WITH CLOSING PART S2




Mounting the lock

Tighten the screws with feeling and do not use drills or cordless drill or cordless screwdriver.

MOUNTING LEFT WITH CLOSING PART S2





MOUNTING RIGHT WITH CLOSING PART S2



Mounting the lock

Tighten the screws with feeling and do not use drills or cordless drill or cordless screwdriver.

MOUNTING RIGHT WITH CLOSING PART S2



XLOCK GATEWAYS

Optional! Please order separately.



XLOCK Gateway G2-WIFI incl.
USB C charging cable.
2.4 GHz WIFI compatible USB
power supply required

 Bluetooth™



XLOCK Gateway G3-
Ethernet incl. USB C charging
cable.
USB power supply required

 Bluetooth™



XLOCK Gateway G3 POE-Ethernet
incl. USB C charging cable.
POE does not require a separate
power supply

 Bluetooth™



BLUETOOTH ACCESSORIES

Optional ! Please order separately.



With the Wireless Key and the Wireless Keypad, the lock can be unlocked over a distance of up to 20 meters - cable-free.

The wireless keypad can be used to program all XLOCK pin code functions such as fixed, time and one-time code.



XLOCK BLE
Wireless keyboard



XLOCK BLE
Wireless key



XLOCK

More information and support at
www.xlockgroup.com

XLOCK by data mobile

Landstrasse 35-39

AUT - 6911 Lochau

info@xlockgroup.com

www.xlockgroup.com