

## // INCLUDED PARTS


Lock	Smartbox SB40
Emergency opening	2 Mechanical keys and USB cable
Accessory	Hanging bracket
Mounting	Screws and dowels for mounting

## // IMPORTANT

- We recommend that you use lithium batteries from Energizer.
- We recommend that you keep the Smartbox 40 open until it's installed correctly in the XL Lock Manager app.
- Preprogrammed Pin-Code to unlock the box is 123456#
- IP65 (water-proof, if used correctly).

\*The Smartbox 40 must be mounted on a flat surface. The cover and the rubber protection for the Micro USB-C must always be closed when not in use. If the Smartbox is opened while raining, the wet areas must be wiped dry. The mechanical emergency keys should be kept safe and within reach and must under no circumstances fall into unauthorized hands.

## // RESET



If you do not see the lock in the XL Lock Manager App search list after inserting the batteries, you can do a hard reset of the lock. To do so, press the reset button as shown on the picture for 3 seconds until a long sound arises. After the sound, the lock will be shown in the App, ready to be initialised.

The following PIN-Code is preprogrammed to unlock the keybox before initialising in the XL Lock Manager App: 123456#

## // GUIDES AND MORE



Please scan the QR code with your Smartphone and a website with all the information will open.

If you are working on a PC, you can click on the QR code and a website with all the information will open.

## // PACKAGING



Packaging can be disposed free of charge at the appropriate collection points - paper in the paper garbage can, plastics in the yellow bag and glass in the used glass container.

## XLOCK SB40



## // TECHNICAL DETAILS

Size	140mm x 80mm
Material	Metal and stainless steel
Temperature	-25°C to +55°C
Battery	4 x AAA Energizer lithium batteries
Battery life	Up to 20,000 openings, 2+ years
Compatibility	XL Lock Manager App (iOS, Android) Web Interface ( <a href="http://www.xlock.app">www.xlock.app</a> )
Accessibility	Smartphone via Bluetooth, ID Card, PIN Code, Fingerprint
Gateway	Compatible (to be ordered separately)
Emergency opening	Micro USB C port and Mechanical key
Memory	Unlimited smartphone users via XL Lock Manager App, up to 200 ID cards, up to 150 PIN Codes, up to 100 fingerprints
IP class	IP65*

## // MAINTENANCE

- Use only a dry and soft cloth for cleaning.
- Do not use any cleaning agents or chemicals.
- Store the product in a cool and dry place.
- Store the product out of reach of children and in a dry and dust-protected environment when not in use for a longer period of time.
- Keep the original packaging for transport.

## // DISPOSABLE INFO



According to the European WEEE Directive, electrical and electronic equipment must not be disposed of with household waste. Their components must be recycled or disposed of separately, because toxic and hazardous components can cause lasting damage to health and the environment if disposed of improperly. As a consumer, you are obliged under the Electrical and Electronic Equipment Act (ElektroG) to return electrical and electronic equipment free of charge at the end of its service life to the manufacturer, the point of sale or to public collection points set up for this purpose. Details are regulated by the respective state law. The symbol on the product, the operating instructions and/or the packaging indicates these regulations. By separating, recycling and disposing of old equipment in this way, you are making an important contribution to protecting our environment.

## // SET BEINHALTET


Schloss	Smartbox SB40
Notöffnung	2 Mechanische Schlüssel und USB Kabel
Accessory	Hängehalterung
Montage	Schrauben und Dübel für die Montage

## // WICHTIG

- Wir empfehlen die Verwendung von Lithiumbatterien (Marke: Energizer).
- Wir empfehlen die Smartbox 40 so lange geöffnet zu lassen, bis sie korrekt in der XL Lock Manager-App installiert ist.
- Der vorprogrammierte PIN-Code zum Entsperren der Box lautet 123456#.
- IP65 (wasserdicht, bei korrekter Anwendung).

\*Die Smartbox 40 muss auf einer ebenen Fläche montiert werden. Die Abdeckung und der Gummischutz für den Micro USB-C müssen bei Nichtgebrauch immer geschlossen sein. Wird die Smartbox bei Regen geöffnet, müssen die nassen Stellen trockengewischt werden. Die mechanischen Notschlüssel sollten sicher und griffbereit aufbewahrt werden und dürfen auf keinen Fall in unbefugte Hände geraten.

## // SCHLOSS ZURÜCKSETZEN



Wenn Sie die Smartbox nach dem Einlegen der Batterien nicht in der Suchliste des XL Lock Managers sehen, können Sie das Schloss zurücksetzen. Suchen Sie dazu den Reset-Knopf auf der Rückseite der Vorderschale. Wenn das Gerät eingeschaltet/ geöffnet ist, drücken Sie die Reset-Taste 3 Sekunden.

Mit dem vorprogrammierten PIN-Code (123456#), können Sie die Schlüsselbox bevor der App-Installation öffnen. Der vorprogrammierte PIN-Code wird nach Programmierung in der App automatisch gelöscht.

## // ANLEITUNGEN UND MEHR



Bitte scannen Sie den QR-Code mit Ihrem Smartphone, es öffnet sich dann eine Webseite mit allen Informationen.

Falls Sie am PC arbeiten, können Sie den QR Code anklicken, es öffnet sich dann eine Webseite mit allen Informationen.

## // VERPACKUNG



Verpackungen können kostenlos in den entsprechenden Sammelstellen entsorgt werden - Papier in der Papiertonne, Kunststoffe im gelben Sack und Glas im Altglas-Container.

## XLOCK SB40



## // TECHNISCHE DETAILS

Größe	140mm x 80mm
Material	Metall und Edelstahl
Temperatur	-25°C bis +55°C
Batterie	4 x AAA Energizer Lithium Batterien
Batterielaufzeit	Bis zu 20.000 Öffnungen, 2+ Jahre*
Kompatibilität	XL Lock Manager App (iOS, Android) Web Interface (www.xlock.app)
Zugang	Smartphone via Bluetooth, ID Karte, PIN Code, Fingerprint
Gateway	Kompatibel (seperat zu bestellen)
Notöffnung	Micro USB C Anschluss und mechanische Schlüssel
Speicher	Unbegrenzte Smartphonebenutzer via XL Lock Manager App, bis zu 200 ID Karten, bis zu 150 PIN Codes, bis zu 100 Fingerprints
IP Klasse	IP65*

## // WARTUNG

- Verwenden Sie nur ein trockenes und weiches Tuch zum Reinigen.
- Verwenden Sie keine Reinigungsmittel und Chemikalien.
- Lagern Sie das Produkt kühl und trocken.
- Lagern Sie das Produkt bei längerem Nichtgebrauch für Kinder unzugänglich und in trockener und staubgeschützter Umgebung.
- Heben Sie die Originalverpackung für den Transport auf.

## // EINWEGINFORMATION



Elektrische und elektronische Geräte dürfen nach der europäischen WEEE Richtlinie nicht mit dem Hausmüll entsorgt werden. Deren Bestandteile müssen getrennt der Wiederverwertung oder Entsorgung zugeführt werden, weil giftige und gefährliche Bestandteile bei unsachgemäßer Entsorgung die Gesundheit und Umwelt nachhaltig schädigen können. Sie sind als Verbraucher nach dem Elektroggesetz (ElektroG) verpflichtet, elektrische und elektronische Geräte am Ende ihrer Lebensdauer an den Hersteller, die Verkaufsstelle oder an dafür eingerichtete, öffentliche Sammelstellen kostenlos zurückzugeben. Einzelheiten dazu regelt das jeweilige Landesrecht. Das Symbol auf dem Produkt, der Betriebsanleitung und/oder der Verpackung weist auf diese Bestimmungen hin. Mit dieser Art der Stofftrennung, Verwertung und Entsorgung von Altgeräten leisten Sie einen wichtigen Beitrag zum Schutz unserer Umwelt.